

Homeowner Certification and Instructions for Tap Sample Collection

Vlehla

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

- Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick up by the water department staff.
- A minimum 6-hour period during which there is no water use throughout the house must be achieved prior
 to sampling. The water department recommends that either early mornings or evenings upon returning
 home are the best sampling times to ensure that the necessary stagnant water conditions exist.
- A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000 ml" and turn off the water.
- Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
- IF ANY PLUMBING REPAIRS OR REPLACMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATIN ON THIS FORM BELOW.
- Place the sample kit and the completed certification form below outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
- Results from this monitoring effort will be provided to participating customers when reports are generated
 for the State unless excessive lead and or copper levels are found. In those cases, immediate notification
 will be provided (usually 10 working days from the time of sample collection).

Call Scott instructions.	at (720) 587-7740 if you have any questions regarding thes
Call COTT instructions.	at (720) 587-7740 if you have any questions regarding the

Certification of Resident Sampling Form:

TO BE COMPLETED	BY RESIDENT
Water was last used: 5	23/13 Time: 1/300 PM
Sample was collected: \ / 2	# 1/3 Time: 8:00 And
I have read the above direction	is and have taken a tap sample in accordance with these directions.
Signature Type	> S 24 13
Additional Comments or Notat	ions:
Will pich up	Thursday Morning 5/23/13



530 Alpensee

Homeowner Certification and Instructions for Tap Sample Collection

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

- Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick up by the water department staff.
- A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
 A kitchen or bathscorp cold, water forms in that the necessary stagnant water conditions exist.
- A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below
 the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000 ml" and turn
 off the water.
- Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
- IF ANY PLUMBING REPAIRS OR REPLACMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATIN ON THIS FORM BELOW
- Place the sample kit and the completed certification form below outside of the residence in the location of
 the kit's delivery so that department staff may pick up the sample kit
- 7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection).

Certification of Resident Sampling Form:

Water was last used: 5-22-13	Time. VI A PAN
Sample was collected: 5-23-13	Time: 7:00AM
have read the above directions and have tal	ken a tap sample in accordance with these directions. 5-23-13 Date
dditional Comments or Notations:	
Will pick up Thu	sday Morning 5/23/13



475 Alpensee

Homeowner Certification and Instructions for Tap Sample Collection

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.


- Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick up by the water department staff.
- A minimum 6-hour period during which there is no water use throughout the house must be achieved prior
 home are the best sampling times to ensure that the necessary stagnant water conditions exist.
- A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below off the water.
- Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
- IF ANY PLUMBING REPAIRS OR REPLACMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATIN ON THIS FORM BELOW.

 6. Place the sample kit and the completed and the complete and the complete
- Place the sample kit and the completed certification form below outside of the residence in the location of
 the kit's delivery so that department staff may pick up the sample kit.
 Results from this monitoring effort will be a sample kit.
- Results from this monitoring effort will be provided to participating customers when reports are generated
 for the State unless excessive lead and or copper levels are found. In those cases, immediate notification
 will be provided (usually 10 working days from the time of sample collection).

Call Scott	at (720) 587-774 Byou have any questions regarding these
_	

Certification of Resident Sampling Form.

	COOPERATION RECEIVED TO THE STATE OF THE STA
Sample w	ras collected: 5/23/13 Time: 11:30 pm Time: 6:20 am Ind the above directions and have taken a tap sample in accordance with these directions.
1 1	lina Thamas 5/23/12
Additional	Comments or Notations:
Wil	1 Pich up Thursday Morning 5/23/13



Homeowner Certification and Instructions for Tap Sample Collection

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

- Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick up by the water department staff.
- A minimum 6-hour period during which there is no water use throughout the house must be achieved prior to sampling. The water department recommends that either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist.
 A kitchen or hathroom sold water found in the necessary stagnant water conditions exist.
- A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below off the water.
 Tightly can the cold water tap. Fill the sample bottle to the line marked "1000 ml" and turn.
- Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
- 5. IF ANY PLUMBING REPAIRS OR REPLACMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATIN ON THIS FORM BELOW
- Place the sample kit and the completed certification form below outside of the residence in the location of the kit's delivery so that department staff may pick up the sample kit.
- Results from this monitoring effort will be provided to participating customers when reports are generated
 for the State unless excessive lead and or copper levels are found. In those cases, immediate notification
 will be provided (usually 10 working days from the time of sample collection).

Certification of Resident Sampling Form.

COVIDE MEDITALISM CONTRACTOR	A TOTAL PROPERTY OF THE PARTY O
Water was last used: 5/22/13	Time: 11:00 Pm
Sample was collected: 5 / 2-2 / /3	Time: 1/ 1/0 /
I have read the above directions and have taken a ta	p sample in accordance with these directions
Signature	5/23/18 Date
Additional Comments or Notations:	
VILL PICH UP Thursday	Morning 5/23 (13



Homeowner Certification and Instructions for Tap Sample Collection

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

A sample is to be collected after water has been sitting in the pipes for an extended period of time (i.e., no water use during this period). Due to this requirement, either early mornings or evenings upon returning from work are the best times for collecting samples. The collection procedure is described in more detail below.

- Prior arrangements will be made with the customer to coordinate the sample collection event. Dates will be set for sample kit delivery and pick up by the water department staff.
- A minimum 6-hour period during which there is no water use throughout the house must be achieved prior
 to sampling. The water department recommends that either early mornings or evenings upon returning
 home are the best sampling times to ensure that the necessary stagnant water conditions exist.
- A kitchen or bathroom cold-water faucet is to be used for sampling. Place the sample bottle (open) below the faucet and gently open the cold water tap. Fill the sample bottle to the line marked "1000 ml" and turn off the water.
- Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.
 IF ANY PLUMBING REPAIRS OF PROPERTY.
- IF ANY PLUMBING REPAIRS OR REPLACMENT HAS BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATIN ON THIS FORM BELOW.

 Place the sample kit and the completed and for the property of the sample of the
- Place the sample kit and the completed certification form below outside of the residence in the location of
 the kit's delivery so that department staff may pick up the sample kit.
- 7. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and or copper levels are found. In those cases, immediate notification will be provided (usually 10 working days from the time of sample collection)

Callinstruct	Scott ons.	at (720)	587-7740	If you have any q	uestions regarding these

Certification of Resident Sampling Form:

Water was last used: 5/28/13	Time: 9:40 p.m
Sample was collected: 5/29/13	Tune / -
and have t	aken a tap sample in accordance with these directions.
gnature	$\frac{5/z^{\frac{9}{13}}}{Date}$
dditional Comments or Notations:	
.// / -/	sday morning 5/23/13